

USING AIRMASK

AirMask®

AirMask is designed for cold machine application.

Unwind and apply AirMask with a laminator machine onto the graphic.

Make sure to turn off the brake and the adhesive side of AirMask should face the graphic.

Application

1. Install the vinyl graphic on the designated area of your laminator machine (vinyl facing up).
2. Install the roll of AirMask with the adhesive side facing the vinyl, on the designated area of the laminator machine and turn off the brake.
3. When the lamination process is done, turn the graphic upside down and peel the liner away from the graphic or peel the application tape away from the liner.
4. Apply the graphic to its target surface with the vinyl facing the surface.
5. Squeegee the graphic onto the target surface from the centre out to remove bubbles. AirMask was designed to reduce bubbles so this will be easier. Make sure the graphic adheres fully to the target surface.
6. Remove the AirMask from the applied graphic by peeling back at an angle of 45° and discard the transfer tape.